GENERAL DESIGN GUIDELINES

- 1 SHOW SECTION NUMBER, RANGE AND TOWNSHIP.
- 2 SHOW TIES TO CENTERLINE FROM GOVERMENT CORNERS / ALIGNMENT TIES AT CROSSROADS.
- 3 SHOW ALIGNMENT CURVE DATA ON SHEET WHERE P.I. APPEARS / ALONG WITH COORDINATES AT P.I., P.C. AND P.T. NOTE: \bigtriangledown

POINTS TO CENTER OF ARC

- 4 SHOW ALL BEARING & ANGLES TO THE NEAREST 1 SECOND
- 5 SHOW ALL TIES, DIMENSIONS & COORDINATES TO THE NEAREST HUNDREDTH



